


# FENDER PRINCETON AMP



- 1 - 50,000 ohm resistor
- 2 - 5 Meg. " "
- 3 -  $\frac{1}{4}$  Meg. " "
- 4 - 5,000 " "
- 5 - 1 Meg. control
- 6 - AC switch on tone control
- 7 -  $1\frac{1}{2}$  Meg. ohm resistor
- 8 - 500 " "
- 9 - 50,000 " "

- 10 - .01 Mfd. 600 V. Cond.
- 11 - .0005 Mfd.
- 12 - 25 Mfd. x 25 Volt. Cond.
- 13 - 8 Mfd. x 450 Volt. Cond.
- 14 - Output transformer #7765
- 15 - 2 amp fuse
- 16 - Speaker
- 17 - Power transformer #6500

FENDER MUSICAL INSTRUMENTS  
 A DIVISION OF COLUMBIA RECORDS DISTRIBUTION CORP.  
 SANTA ANA, CALIFORNIA  
 U.S.A.